

	Firmware Server Support Guide
	8.10
BL Series	
BL20p G3	✓
BL20p G4	✓
BL25p G2	✓
BL35p	✓
BL45p G2	✓
BL2x220c G5	✓
BL260c	✓
BL460c	✓
BL465c	✓
BL465c G5	✓
BL480c	✓
BL680c G5	✓
BL685c	✓
BL685c G5	✓
DL Series	
DL320 G3	✓
DL320 G4	✓
DL320 G5	✓
DL320 G5p	✓
DL320s	✓
DL360 G4	✓
DL360 G4p	✓
DL360 G5	✓
DL365	✓
DL365 G5	✓
DL380 G4	✓
DL380 G5	✓
DL385	✓
DL385 Packaged Cluster - MSA500 G2	✓
DL385 G2	✓
DL385 G5	✓
DL580 G2	✓
DL580 G3	✓
DL580 G4	✓
DL580 G5	✓
DL585	✓
DL585 G2	✓
DL585 G5	✓
DL785 G5	✓
ML Series	
ML310 G4	✓
ML310 G5	✓
ML350 G4	✓
ML350 G4p	✓
ML350 G5	✓
ML370 G4	✓
ML370 G5	✓
ML570 G3	✓
ML570 G4	✓

	Servers First Supported on Firmware CD											
	8.00	7.91	7.90	7.80	7.70	7.61	7.60	7.50	7.40	7.30	7.20	7.10
BL Series												
BL10e	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
BL10e G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
BL20p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
BL20p G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
BL20p G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
BL20p G4	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
BL25p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
BL25p G2	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
BL30p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
BL35p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
BL40p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
BL45p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
BL45p G2	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
BL460c	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
BL465c	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
BL480c	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
BL680c G5	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
BL685c	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL Series												
DL320	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL320 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL320 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL320 G4	✓	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘
DL320 G5	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL320 G5p	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL320s	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL360	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL360 G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL360 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL360 G4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL360 G4p	✓	✓	✓	✓	✓	✓	✓	✓	⊘	⊘		⊘
DL360 G5	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
DL365	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL380	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL380 G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL380 G2 Packaged Cluster	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL380 G3	⊘	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL380 G3 Packaged Cluster - MSA500	⊘	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL380 G3 Packaged Cluster - MSA1000	⊘	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL380 G4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL380 G4 Packaged Cluster - MSA500 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘

	Servers First Supported on Firmware CD											
	8.00	7.91	7.90	7.80	7.70	7.61	7.60	7.50	7.40	7.30	7.20	7.10
DL380 G4 Packaged Cluster - MSA1000	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL380 G5	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
DL385	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL385 Packaged Cluster - MSA500 G2	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
DL385 G2	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL560	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL580	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
DL580 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL580 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL580 G4	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
DL580 G5	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL585	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
DL585 G2	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
DL590-64	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓
DL740	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL760	⊘	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DL760 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML Series												
ML310	⊘	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML310 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
ML310 G3	✓	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘
ML310 G4	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘
ML310 G5	✓	✓	✓	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
ML330	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML330 G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML330 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML330e	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML350	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML350 G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML350 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML350 G4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
ML350 G4p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
ML350 G5	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
ML370	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML370 G2	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML370 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML370 G4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
ML370 G5	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘
ML530	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML530 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML570	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
ML570 G2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ML570 G3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	⊘
ML570 G4	✓	✓	✓	✓	✓	✓	✓	⊘	⊘	⊘	⊘	⊘

	Servers First Supported on Firmware CD											
	8.00	7.91	7.90	7.80	7.70	7.61	7.60	7.50	7.40	7.30	7.20	7.10
ML750	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓	✓	✓
Other ProLiant												
ProLiant 400	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 800	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 850r	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 1000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 1200	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 1500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 1600	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 1850r	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 2000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 2500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 3000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 4000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 4500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 5000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 6000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 6500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 7000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 5500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 6400	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
ProLiant 6400r	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 8000	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant 8500	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant CL1850	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
ProLiant CL380	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	✓	✓	✓
Prosignia 720	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘
Prosignia 740	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘	⊘

✓ Support
⊘ No Support