HP EMEA UPS Power Cord and Jumper Cord Matrix

uild use the local power cord (which is shipped with the servers) for the UPS and could use the C13 to C14 (jumper) thipped with the UPS) to connect the server to the UPS.

HP UPS UPS Model	**All countries will receive the mainland Europe power cord, unless the country is spefically noted on this chart.								
UPS Model	·								
UPS Model	HP Part	Country	Input Power Cable	Input Plug	Output Plug	Power Cable	Quantity		
	number		attached to UPS			shipped with			
T750	378439-B31	Mainland Europe	No	IEC C13	IEC 83 C4 (CEE7-	IEC C13 to C14*	1		
		(Germany, France,)			VII) / Schuko				
T750	378439-B31	UK	No	IEC C13	BS 1363/A	IEC C13 to C14*	1		
T750	378439-B31	Denmark	No	IEC C13	DK 2-5A	IEC C13 to C14*	1		
T750	378439-B31	Italy	No	IEC C13	CEI 23-50	IEC C13 to C14*	1		
T750	378439-B31	South Africa	No	IEC C13	SABS 164	IEC C13 to C14*	1		
							1		
T750	378439-B31	Israel	No	IEC C13	SI 32	IEC C13 to C14*	1		
T750	378439-B31	Switzerland	No	IEC C13	SEV 1011	IEC C13 to C14*	1		
T1000G2	AF405A	Mainland Europe	No	IEC C13	IEC 83 C4 (CEE7-	IEC C13 to C14*	1		
		(Germany, France,)			VII) / Schuko		_		
T1000G2	AF405A	UK	No	IEC C13	BS 1363/A	IEC C13 to C14*	I		
T1000G2	AF405A	Denmark	No	IEC C13	DK 2-5A	IEC C13 to C14*	1		
T1000G2	AF405A	Italy	No	IEC C13	CEI 23-50	IEC C13 to C14*	1		
T1000G2	AF405A	South Africa	No	IEC C13	SABS 164	IEC C13 to C14*	1		
T1000G2	AF405A	Israel	No	IEC C13	SI 32	IEC C13 to C14*	1		
				IEC C13			1		
T1000G2	AF405A	Switzerland	No		SEV 1011	IEC C13 to C14*	1		
T1500G2	AF408A	Mainland Europe	No	IEC C13	IEC 83 C4 (CEE7- VII) / Schuko	IEC C13 to C14*	1		
T1500C0	454004	(Germany, France,)	N	IEC C12		IFC C12 : C1 !:	,		
T1500G2	AF408A	UK	No	IEC C13	BS 1363/A	IEC C13 to C14*			
T1500G2	AF408A	Denmark	No	IEC C13	DK 2-5A	IEC C13 to C14*	1		
T1500G2	AF408A	Italy	No	IEC C13	CEI 23-50	IEC C13 to C14*	1		
T1500G2	AF408A	South Africa	No	IEC C13	SABS 164	IEC C13 to C14*	1		
T1500G2	AF408A	Israel	No	IEC C13	SI 32	IEC C13 to C14*	1		
							1		
T1500G2	AF408A	Switzerland	No	IEC C13	SEV 1011	IEC C13 to C14*	1		
R/T2200G2**	AF411A	Mainland Europe	No	IEC C13	IEC 83 C4 (CEE7-	IEC C19 to IEC83	1		
		(Germany, France,)			VII) / Schuko	C4 (CEE7-VII)			
R/T2200G2**	AF411A	UK	No	IEC C19	BS 1363/A	IEC C19 to BS 1363/A	1		
R/T2200G2**	AF411A	UK	No	IEC C19	BS 1363/A	IEC C19 to BS	1		
						1363/A			
R/T2200G2**	AF411A	Denmark	No	IEC C19	DK 2-5A	IEC C19 to DK2-5a	1		
R/T2200G2**	AF411A	Italy	No	IEC C19	CEI 23-50	IEC C19 to CEI 23- 50	1		
R/T2200G2**	AF411A	South Africa	No	IEC C19	SABS 164	IEC C19 to SAB 164	1		
R/T2200G2**	AF411A	Israel	No	IEC C19	SI 32	TBD	1		
R/T2200G2**	AF411A	Switzerland	No	IEC C19	DK 2-5A	IEC C19 to DK2-5a	1		
R1500G2	AF418A	Mainland Europe	No	IEC C13	IEC 83 C4 (CEE7-	IEC C13 to C14*	1		
		(Germany, France,)			VII) / Schuko				
R1500G2	AF418A	UK	No	IEC C13	BS 1363/A	IEC C13 to C14*	1		
R1500G2	AF418A	Denmark	No	IEC C13	DK 2-5A	IEC C13 to C14*	1		
R1500G2	AF418A	Italy	No	IEC C13	CEI 23-50	IEC C13 to C14*	1		
R1500G2	AF418A	South Africa	No	IEC C13	SABS 164	IEC C13 to C14*	1		
R1500G2	AF418A	Israel	No	IEC C13	SI 32	IEC C13 to C14*	1		
							-		
R1500G2	AF418A	Switzerland	No	IEC C13	SEV 1011	IEC C13 to C14*	I		
R3000**	AF414A	Mainland Europe	No	IEC C19	IEC 83 C4 (CEE7-	IEC C19 to IEC83	1		
R3000**	AF414A	(Germany, France,) UK	No	IEC C19	VII) / Schuko BS 1363/A	C4 (CEE7-VII) IEC C19 to BS	1		
K3000**	AF414A	UK.	140	IEC C19	B3 1303/A	1363/A	'		
R3000**	AF414A	UK	No	IEC C19	BS 1363/A	IEC C19 to BS	1		
R3000**	AF414A	Denmark	No	IEC C19	DK 2-5A	1363/A IEC C19 to DK2-5a	1		
K3000**	AF414A	Denmark	No	IEC C19	DK 2-5A	IEC C19 to DK2-5a	1		
R3000**	AF414A	Italy	No	IEC C19	CEI 23-50	IEC C19 to CEI 23- 50	1		
R3000**	AF414A	South Africa	No	IEC C19	SABS 164	IEC C19 to SAB 164	1		
R3000**	AF414A	Israel	No	IEC C19	SI 32	TBD	1		
R3000**	AF414A	Switzerland	No	IEC C19	DK 2-5A	IEC C19 to DK2-5a	1		
R5500	AF416A	Mainland Europe (Germany, France,)	yes	Attached IEC 309 32A, single phase	IEC 309 32A	IEC 309 32A, attached cord to	1		
R5500	AF416A	UK	yes	to UPS Attached IEC 309	IEC 309 32A	UPS IEC 309 32A,	1		
				32A, single phase to UPS		attached cord to UPS			
		Denmark	yes	Attached IEC 309 32A, single phase	IEC 309 32A	IEC 309 32A, attached cord to	1		
R5500	AF416A	Definition							
R5500		Definition		to UPS		UPS			
	AF416A AF416A	Italy	yes	to UPS Attached IEC 309 32A, single phase	IEC 309 32A	UPS IEC 309 32A, attached cord to	1		
R5500			yes	to UPS Attached IEC 309	IEC 309 32A	UPS IEC 309 32A, attached cord to UPS	1		
R5500	AF416A			to UPS Attached IEC 309 32A, single phase	IEC 309 32A	UPS IEC 309 32A, attached cord to	1		
R5500		Italy	yes	to UPS Attached IEC 309 32A, single phase to UPS Attached IEC 309 32A, single phase		UPS IEC 309 32A, attached cord to UPS IEC 309 32A, attached cord to	1		
R5500 R5500	AF416A AF416A	Italy South Africa	yes	to UPS Attached IEC 309 32A, single phase to UPS Attached IEC 309 32A, single phase to UPS		UPS IEC 309 32A, attached cord to UPS IEC 309 32A, attached cord to UPS UPS UPS UPS	1		
R5500	AF416A	Italy		to UPS Attached IEC 309 32A, single phase to UPS Attached IEC 309 32A, single phase	IEC 309 32A	UPS IEC 309 32A, attached cord to UPS IEC 309 32A, attached cord to	1		

R5500	AF416A	Switzerland	yes	Attached IEC 309	IEC 309 32A	IEC 309 32A,	1
				32A, single phase		attached cord to	
				to UPS		UPS	

[©] Copyright 2007 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.