

Compaq StorageWorks MSL5026SL Library Configuration Guide

MSL5026SL,1 SDLT 110/220,LVD,TT 231822-B21
 MSL5026SL,2 SDLT 110/220,LVD,TT 231822-B22
 MSL5026SL,1 SDLT 110/220,LVD,RM 231892-B21
 MSL5026SL,2 SDLT 110/220,LVD,RM 231892-B22

163083-B21 MDR (1 FC x 2 LVD SCSI)
 218241-B21 MDR (2 FC x 4 LVD SCSI)

MSL5KField Upg SDLT
 110/220 DR, LVD
 231823-B21

MSL5026SL
 0 to 2 drives
 26 slots
 LVD SCSI, VHDCI
 Interface



Upto 7 libraries can
 be connected together

**•Note: maximum two drives
 per SCSI Channel recommended**

Power Cord, (Australia/China/New Zealand) 227098-011
 Power Cord, (South East Asia/India) 157220-AR1
 Power Cord, (Central Europe) 157215-021
 Power Cord, (United Kingdom/Hong Kong) 157216-031
 Power Cord, (Switzerland) 157219-111
 Power Cord, (Italy) 157217-061
 Power Cord, (Denmark) 157218-081
 Power Cord, (Japan) 129867-006

(NA power cord shipped with all units, does not need to be ordered)

SCSI Cable, VHDCI / VHDCI, 6 ft 341174-B21
 SCSI Cable, VHDCI / VHDCI, 12 ft 341175-B21
 SCSI Cable, VHDCI / Wide, 6 ft 341176-B21
 SCSI Cable, VHDCI / Wide, 12 ft 341177-B21
 SCSI Cable, VHDCI / Wide, 10m 201160-B21
 SCSI Cable, VHDCI / Wide, 20m 201160-B23

check the cable-adapter matrix for tape libraries on

<ftp://ftp.compaq.com/pub/products/storageworks/tape-and-optical-storage/adapter-cable-matrix.pdf>

<http://www.compaq.com/products/storageworks/adapters.html>

Fibre Channel Host
 Bus Adapters



Compaq Switch or Hub



64 bit 66 MHz PCI dual
 channel Wide Ultra II SCSI
 adapter (129803-B21)*





3X-KZPCA-AA
 Single Channel Ultra
 SCSI LVD adapter*







Proliant
 8500/ 8000
 7000
 6500/6000
 DL 580/ 6400R
 ML570 / 5500
 ML 530/ 3000
 DL380/1850R
 ML370/1600
 ML350/800
 DL360

CIM v5.0

AlphaServer
 GS 320*,160*,80*
 ES 40/ES45*
 ES20E
 ES10/10L
 *supported in future

MRU v1.4

-  VERITAS Backup Exec V8.5 for Windows NT v8.5 for Novell NetWare
-  CA Arcserve2000 for Win NT/2000
CA ArcserveIT V7.0 for Networkware
-  Legato NetWorker v6.1 for Win NT/2000
-  Veritas NetBackup V3.4 for Win NT/2000 (under EBS only)

-  Legato NetWorker v6.1 for Tru64 Unix
-  Archive Backup System v3.0 for Open VMS
-  Storage Library System v2.9D for Open VMS
-  Veritas NetBackup V3.4 for Tru64Unix (under EBS only)
Supported in future
-  Legato SmartMedia V1.2 for Windows NT and Tru64 Unix
-  Tivoli TSM V4.2 for Win NT/2000

MSL5026SL Multi-unit Configuration

Table Top to Rack Mount Conversion Kits

231894-B22 MSL5026 TT-RK
KIT, COMPAQ RACK



231892-B21 MSL5026SL, 1 SDLT110/220DR, LVD, RM
231892-B22 MSL5026SL, 2 SDLT110/220DR, LVD, RM



Multi-Unit Configurations: upto 7 units can be scaled together

MSL5026 Pass-Thru Mechanism 231824-B21, Required to connect first two units


MSL5026, Pass Through Extender 231824-B22, required one for each unit connected to the stack, for third and more units

PTM elevator mechanism

MSL5026 Pass-Thru Mechanism 231824-B21, includes elevator mechanism and router

Required to connect first two units

Router mounted on side of rack



PT Extender

Ethernet cable