


© 2002 Hewlett-Packard Company

HP and StorageWorks are trademarks of Hewlett-Packard Company in the U.S., and/or other countries. All rights reserved. All other product names mentioned herein may be trademarks of their respective companies. These brackets replace the brackets that ship with the library, for installation into HP Rack System/e rack enclosures.


1. Remove the four screws that attach the rail to the 29-inch bracket that shipped with the library.

NOTE: Reuse these screws when attaching the rail to the 28-inch bracket.

2. Line up the front mounting hole on the 28-inch bracket with the front mounting hole on the rail.



3. Slide the rail out until an opening appears, allowing you to insert the screws.



- 4. Slide the rail back to access the remaining holes. Insert and tighten the remaining screws.
- 5. Refer to Chapter 2 of the *hp StorageWorks MSL5000 Series Library User Guide* to use the rack template and complete the installation.

NOTE: For updates and translated versions of this document, visit our website at: http://www.compaq.com/storage/tape_index.html

HP StorageWorks Rack Adapter Bracket Installation Instructions First Edition (August 2002) Part Number: 306734-001

Hewlett-Packard Company

