Moving HP SIM 5.x to a new Windows system



Introduction	3
Getting started	
Migrating HP SIM 5.x with local MSDE/SQL Server 2005 Express database to another HP SIM systemente MS SQL 2000/SQL 2005 database	4 4
Deleting target CMS from source CMS	6
Migrating from the source CMS to the target CMS Importing the MSDE database from the source CMS to the target CMS Importing the SQL Server 2005 Express database from the source CMS to the target CMS Migrating PMP 4.x.x data from the source CMS to the target CMS Migrating HP SIM 5.X Updating the target CMS details in database PMP license migration Changing the IP address of a system running HP SIM and the Vulnerability and Patch Manageme (VPM) Changing the IP address of a system running HP SIM and VPM on the same system Changing the IP address of systems running HP SIM and VPM on different systems	6 10 11 12 nt Pack 13
Post database migration SSH Configuration Host files and templates WBEM Indication configuration Configuration settings. WMI Mapper configuration Migrating trusted system certificates from the source CMS to the target CMS Steps to replicate certificates from the target CMS to trusted managed systems Replicating the trusted certificates and trust mode from the source CMS to target CMS.	14 15 15 15 15
Migrating HP VMM/HP SMP with a local MSDE database to another HP VMM/HP SMP with remote database	
For more information Microsoft® SQL Express 2005 Microsoft SQL Server 2005 Microsoft SQL Server 2000 Enterprise Edition System requirements HP SIM 5.2 Overview and features Microsoft® Windows® Registry	20 20 20 20
The System Registry	



Introduction

This white paper is intended to assist system administrators in migrating the HP Systems Insight Manager (HP SIM) 5.x database to a new HP SIM 5.x Windows system, including:

- Migrating HP SIM 5.x with local MSDE/SQL Server 2005 Express database to another HP SIM system with remote MS SQL 2000/SQL 2005 database
- Migrating HP SIM 5.x with local MSDE/SQL Server 2005 Express database to another HP SIM system with remote MS SQL 2000/SQL 2005 database
- Migrating from the source CMS to the target CMS
- Migrating HP VMM/HP SMP with a local MSDE database to another HP VMM/HP SMP with remote MS SQL database

Getting started

Target audience

It is assumed that readers of this document have an excellent understanding of the following concepts and services:

- Basic Microsoft® Windows® 2000 services
- Basic Microsoft® Windows® host configuration
- Basic ODBC configuration
- TCP/IP and DNS network concepts

In addition, readers must be familiar with installing and administering:

- Microsoft® Windows® 2000 Server/Advanced Server, Microsoft® Windows® Server 2003 Standard/ Enterprise Edition, MSDE 2000, SQL Express 2005
- Microsoft SQL Server 2000, SQL Server 2005
- HP SIM 5.x

Migrating HP SIM 5.x with local MSDE/SQL Server 2005 Express database to another HP SIM system with remote MS SQL 2000/SQL 2005 database

NOTE: HP does not recommend migrating the HP SIM local database to a new HP SIM system with a local database.

This section assumes you have already configured the following:

- Source central management server (CMS) The system where HP SIM 5.x is installed with MSDE/SQL Server 2005 Express.
- Target CMS The system to which HP SIM 5.x is going to migrate. It assumes that this machine
 meets the prerequisites for the installation of HP SIM 5.x using remote database.
- Database System A system where MS SQL Server 2000/2005 is installed for the remote connection.

For more details about HP SIM 5.x prerequisites, refer to the HP SIM User Guide and HP SIM Release Notes located on the HP Management CD. This section consists of three migration stages:

- Pre-Migration Preparing the existing HP SIM 5.x system for migration.
- Migrating from one system to another Installing HP SIM 5.x on the target CMS and migrating the database from the source CMS to the target CMS.
- Post Migration Replicating the HP SIM 5.x configuration from the source CMS to the target CMS.

Providing MSDE database access for the remote system

To verify that TCP/IP protocol is enabled in SQL Server Network Utility:

- 1. Go to <MSDE Install folder>\ Microsoft SQL Server\80\Tools\Binn.
- Execute the SQL Server Network Utility EXE from this directory using the following command: syrneton

Verify that TCP/IP is listed in the **Enabled Protocols** list. If **Enabled Protocols** is not listed, select **TCP/IP** from the **Disabled Protocols** list and click **Enable**. TCP/IP is moved to the **Enabled Protocols** list, which enables it. Click **OK** to apply the changes.

 Go to Control Panel → Administrative Tools → Services and restart the service named MSSQLSERVER for this change to take effect.

Enabling mixed mode authentication in MSDE

Warning: If the Registry Editor is used incorrectly, it can cause serious problems that require you to reinstall the operating system.

Note: Perform these steps only if Mixed Mode Authentication is not enabled on the source CMS MSDE.

By default, the value of the LoginMode Windows registry sub key is set to 1 for Windows Authentication. To enable Mixed Mode Authentication, the value of the LoginMode Windows registry sub key must be changed to 2.

The location of the LoginMode sub key depends on whether MSDE was installed as the default MSDE instance or as a named instance.

If MSDE was installed as the default instance, the LoginMode sub key is located in the following registry path:

```
HKEY_LOCAL_MACHINE\Software\Microsoft\MSSqlserver\MSSqlServer\LoginMode
```

If MSDE was installed as a named instance, the LoginMode sub key is located in the following registry path:

```
HKEY_LOCAL_MACHINE\Software\Microsoft\Microsoft SQL Server\<Instance Name>\MSSQLServer\LoginMode
```

To change the value of LoginMode to 2, follow these steps:

- 1. Go to Control Panel-Administrative Tools-Services and stop MSSQLSERVER.
- 2. To open the **Registry Editor**, click **Start→Run**, enter **regedit**, and click **OK**.
- Locate one of the following sub keys, depending on whether you installed MSDE as the default MSDE instance or as a named instance:

If MSDE was installed as a default instance:

```
\label{thm:local_machine} \begin{tabular}{l} $\operatorname{MSSqlserver}(MSSqlserver) \\ or \end{tabular}
```

If MSDE was installed as a named instance:

```
\label{local_Machine} $$HKEY_LOCAL_MACHINE\software\Microsoft\Microsoft\SQL\Server\solvenseloop{$\mbox{NSSQLServer}$} $$Name>\mbox{MSSQLServer}$$
```

4. In the right pane, double-click the **LoginMode** sub key.

In the **DWORD Value** dialog box, set the value of this sub key to 2, be sure that the Hexadecimal option is selected, and click **OK**.

- 5. Go to **Control Panel** Administrative **Tools** Services and start the service named **MSSQLSERVER** for this change to take effect.
- 6. Specify a password for the built-in SA user account

Note: Perform these steps only if Mixed Mode Authentication is not enabled on the source CMS MSDE.

The built-in SA user account is installed without a random password. If you enable **SQL Server Authentication**, you must set a new password for this account. To set a new password for the

built-in SA account, follow these steps to use OSQL, which is a command-line utility that is installed with MSDE:

- 1. Login to the source CMS system with administrative privileges.
- Open the command prompt and navigate to < MSDE Install folder>\ Microsoft SQL Server\80\Tools\Binn.
- 3. Run the following command:

```
osql -E
```

4. Enter the following commands, one at a time to change the password for the SA user account:

NOTE: Be sure that you replace < *new password>* with the new password.

- 1. sp_password @new='<new password>', @loginame='sa'
- 2. go

A message appears indicating that the password for the SA user account was changed:

Deleting target CMS from source CMS

NOTE: Perform these steps only if the target CMS is discovered in the source CMS.

- 1. Enter the target CMS name or IP address in the **Search** field and click **Search**.
- 2. Select the system and click **Delete**. A confirmation message appears.
- 3. Click **OK** to confirm the deletion of the target CMS from the source CMS.

Migrating from the source CMS to the target CMS

Importing the MSDE database from the source CMS to the target CMS

IMPORTANT: Be sure that the source and target CMS systems are registered with the same DNS server. If the target CMS is registered to a different DNS be sure that the DNS is able to resolve all of the managed systems that will be migrated. This is required for the migration to succeed correctly.

While installing HP SIM 5.1 on the target CMS, be sure that it is pointing to the correct database system where SQL 2000 is running.

To import the MSDE database from the source CMS to the target CMS:

- 1. Install HP SIM 5.1 on the target CMS.
- Go to Control Panel→Administrative Tools→Services and stop the HP SIM, HP Performance Management Pack, and HP PMP Tools services.
- 3. Go to Start→Settings→Control Panel→Administrative Tools→Data Sources (ODBC) and select the System DSN tab.
- 4. Select the DSN named **Insight_v50_0** and click **Configure.**

- From the Microsoft SQL Server DSN Configuration wizard, write down the remote database name that is configured by default and click **Cancel** to exit the wizard without making any changes.
- 6. Logon to the database system, as Administrator.
- 7. Select Start-Programs-Microsoft SQL Server-Enterprise Manager.
- 8. Click + to expand the list pointing to Microsoft SQL Servers in the left pane.
- 9. Select **SQL Server Group** and right click to select **New SQL Server Registration**. The Register SQL Server wizard appears.
- 10. Click Next.
- 11. From **Available servers** list, select the source **CMS**.
- 12. Click **ADD** to add this system to the **Added server** list. If this server does not appear in the **Available servers** list, enter the system name or IP address manually in the **Available servers** text box and click **Add** to add this server to the **Added Servers** list manually.
- 13. Click **Next.** The **SQL Server authentication** page appears.
- 14. Click Next.
- 15. Select the default option Add the SQL server(s) to an existing SQL Server group and click Next.
- 16. Click **Finish**. A message appears indicating that the server registration is complete.
- 17. Click **Close** to complete the configuration wizard.
- 18. Launch Enterprise Manager. Click + to expand the list adjacent to **Microsoft SQL Servers** to list SQL Server Group.
- 19. Click + to expand the SQL Server Group node.
- 20. Select the source CMS and then select **Databases**.
- 21. From the right pane, right-click on the database **Insight_v50_0<** (the database of source CMS) and select **All Tasks**.
- 22. Select **Export Data**.
- 23. Click Next.
- 24. DTS IMPORT/EXPORT Wizard appears, with Choose a Data Source option.
- 25. Select the source CMS (MSDE) as the server and the database as **Insight v50 0<**xxxx>.
- 26. Select Use SQL Server Authentication and enter the credentials for user SA.
- 27. Click **Next**. The **Choose a destination** dialog box appears.
- 28. Select **local** (which is the target CMS running SQL 2000 Database) as the server and the database as Insight_v50_0<**xxxx>** (Refer to step 5 in this section for the remote database name. If the system is not listed, manually enter the system name or IP Address of the remote system).
- 29. Select the required authentication. Select **Windows Authentication** or **SQL Server Authentication**.

- 30. Click Next.
- 31. Select Copy objects and data between SQL Server databases and click Next.
- 32. Select **Include extended properties** and leave all the other default options selected. Click **Next**. The **Save**, **schedule and replicate Package** window appears.
- 33. Retain the default options and click **Next**.
- 34. Review the **Summary** and click **Finish**. The export process starts immediately. A message appears: **Successfully copied objects from Microsoft SQL Server to SQL Server**.

If an error message appears indicating Failed to copy objects from Microsoft SQL Server to Microsoft SQL Server while importing the MSDE database from the source CMS to the target CMS, use the following workaround:

- a. Beginning with step 32 above, select Include extended properties and deselect Copy all objects. Notice that the Select Objects button is enabled. Leave all default options selected.
- Click Select Objects. In the Select Objects dialog box, select all objects except the R ArrayControllers object.
- c. Click OK.
- d. Click **Next**. The **Save, schedule and replicate Package** window appears. Retain the default options and click **Next**.
- Review the Summary and click Finish. The export process starts immediately. A
 message appears: Successfully copied objects from Microsoft SQL Server to
 SQL Server.
- f. To copy only the **R_Arraycontrollers** object, select the source CMS and then select **Databases**.
- g. From the right pane, right-click on the database **Insight_v50_0**xxxx (the database of source CMS) and select **All Tasks**.
- h. Select **Export Data**.
- i. Click Next.
- j. DTS IMPORT/EXPORT Wizard appears, with **Choose a Data Source** option.
- k. Select the source CMS (MSDE) as the server and the database as **Insight_v50_0<**xxxx>.
- 1. Select **Use SQL Server Authentication** and enter the credentials for user SA.
- m. Click **Next**. The **Choose a destination** dialog box appears.
- n. Select **local** (which is the target CMS running SQL 2000 Database) as the server and the database as Insight_v50_0<**x**x*> (Refer to step 5 in this section for the remote database name. If the system is not listed, manually enter the system name or IP Address of the remote system).
- o. Select the required authentication. Select **Windows Authentication** or **SQL Server Authentication**.

- p. Click Next.
- q. Select Copy objects and data between SQL Server databases and click Next.
- r. Select **Include extended properties** and deselect **Copy all objects**. Notice that the **Select Objects** button is enabled. Leave all default options selected.
- s. Click **Select Objects**. In the **Select Objects** dialog box, select only the **R_ArrayControllers** object.
- t. Click OK.
- Click Next.
- v. Retain the default options and click **Next**.
- w. Review the Summary and click Finish. The export process starts immediately. A message appears: Successfully copied objects from Microsoft SQL Server to SQL Server.
- x. Click Done.

35. Click Done.

Importing the SQL Server 2005 Express database from the source CMS to the target CMS

Note: SQL Server 2005 Express cannot be connected to MS SQL 2000.

While installing HP SIM 5.2 on the target CMS, be sure that it is pointing to the correct database system where SQL 2000 is running.

To import the SQL Server 2005 Express database from the source CMS to the target CMS:

- 1. Install HP SIM 5.2 on the target CMS with remote SQL 2005.
- Go to Control Panel → Administrative Tools → Services and stop the HP SIM, HP Performance Management Pack, and HP PMP Tools services.
- 3. On the target system, run the command mxgetdbinfo, to get the database name. For example, Insight_v50_0_22013812.
- 4. Logon to the database system, as Administrator.
- 5. Install the Client Management Tools on the database system.
- Select Start→Programs→Microsoft SQL Server 2005→SQL Server Management Studio.
- 7. In the Connect to server wizard, select the local system as server and click Connect.
- 8. Click the **Connect** tab in the left panel and select **Database Engine**.
- In the Connect to Server wizard, select the source CMS and Authentication mode and click Connect.
- 10. To rename the database, right click on the target CMS database and select **rename**.

- 11. Right click on the database and select **New Database**.
- 12. In the **New Database** wizard, name the new database with the same name as as the old target database name. For example, Insight_v50_0_22013812.
- 13. Create a new database with same old target database name.
- 14. Right click on source database, select Tasks → Export Data
- 15. The Welcome to SQL server Import and Export wizard displays. Click Next.
- 16. Select the source CMS (SQL server 2005 Express) as the server and the database as **Insight_v50_0**<*xxxx>*.
- 17. Click **Next**. The **Choose a destination** dialog box appears.
- 18. Select the new database created in step 10 and click **Next**.
- 19. For **Specify Table copy or Query**, leave the default settings and click **Next**.
- 20. In the **Select Source Tables and Views** wizard, select all of the tables and views and click **Next**.
- 21. Review the **Summary** and click **Finish**. The export process starts immediately. A message appears: **Successfully copied objects from Microsoft SQL Server to SQL Server**.
- 22. Click Done.

Migrating PMP 4.x.x data from the source CMS to the target CMS

To migrate PMP 4.x.x data from the source CMS system to the target CMS system:

- 1. Login to the database system as administrator.
- 2. To launch Enterprise Manager, select Start→Programs→Microsoft SQL Server→Enterprise Manager.
- 3. From Enterprise Manager, open **Microsoft SQL Servers SQL Servers group-><***local database instance*>>**Databases.**
 - **Note**: The <*local database name*> in most cases is local or it could be the instance you specified.
- 4. From the right pane, right-click on the database **PMP_V3_0**, which is the PMP database on the target CMS, and select **All Tasks→Import Data**. The **DTS import/Export** wizard appears.
- 5. Select **Next.** The **Choose Data Source** dialog box appears.
- 6. Select the source CMS as the server select PMP_V3_0 as the database and click Next.
- 7. From the **Choose destination** page, select *local* (Database system) as the server, and **PMP_V3_0** as the database and select **Windows Authentication** or **SQL Server Authentication** as the required authentication and click **Next**.
- 8. Select Copy objects and data between SQL Server databases and click Next.

- 9. Select Include extended properties and leave all the other default options as selected.
- 10. Click Next. The Save, schedule and replicate Package page appears.
- 11. Retain the default options and click **Next**.
- 12. Review the summary and click **Finish**. The export process starts immediately.
- 13. A message appears: Successfully copied objects from Microsoft SQL Server to SQL Server.
- 14. Click Done.

Note: To migrate PMP 4.x.x data from the source CMS to the target CMS with a local SQL Express 2005 database follow the same steps provided in "Importing the SQL Server 2005 Express database" section.

Migrating HP SIM 5.X

Updating the target CMS details in database

- 1. Login to the database system as Administrator.
- 2. Select Start Menu→Programs→Microsoft SQL Server→Query Analyzer.
- 3. The Device key on the CMS might not always be set to 1. To identify the device key of the source CMS, execute the following SQL Query:

```
Select * from devices where name='<Source CMS name>'
```

- 4. Execute the following SQL queries against the target CMS database.
 - Update devices set name='<Target CMS name>' where devicekey=<Result of Step 3>
 - Update IPAddress set ipaddress='<Target CMS ipaddress>'
 where devicekey=<Result of Step 3> and ipaddress='<Source
 CMS ipaddress>'
 - Update hpmxuser set PersistedName='< Target CMS name >\administrator' where PersistedName='<Source CMS name>\administrator'
 - Update hpmxuser set PersistedName='< Target CMS name >\mxadmin' where PersistedName='< Source CMS name >\mxadmin'
 - Update hpmxuser set PersistedName='< Target CMS name >\handyman' where PersistedName='< Source CMS name >\handyman'
- Execute the following query repeatedly (if required) for all the other local users created in HP SIM.
 - O Update hpmxuser set PersistedName='< Target CMS name
 >\<username>' where PersistedName='< Source CMS name
 >\<username>'

Note: The above query need not be executed for domain users.

- o Update tasks set createdbyuser=replace (createdbyuser,'<
 Source CMS name >','< Target CMS name >')
- o Update tasks set modifiedbyuser=replace (modifiedbyuser,'<
 Source CMS name >','< Target CMS name >')

- 6. Log out of the database system.
- 7. Log into the system where target CMS is installed.
- 8. Go to **Control Panel** → **Administrative Tools** → **Services** and start the services named HP SIM, HP Performance Management Pack, and HP PMP Tools.

PMP license migration

- 1. Log in to the source CMS as administrator.
- 2. Select Start→Run.
- 3. Enter Regedit and click OK. The Registry Editor page appears.
- 4. Expand HKEY_LOCAL_MACHINE\SOFTWARE\HP\Proliant
 Essentials\Licensing\, select 4.x.x and open Export Registry file from registry
 menu.
- 5. Enter a file name and click **Save.** For example, we are using ProEssen as the file name, so we would enter **ProEssen** and click **Save**.
- 6. Copy and save ProEssen to the target CMS.
- 7. Expand HKEY_LOCAL_MACHINE\SOFTWARE\HP\Performance Management Pack\, select **4.x.x** and select **Open Export Registry file** from the registry menu.
- 8. Enter a file name such as PerMgmtPack and click **Save**. For example, we are using PerMgmtPack as the file name, so we would enter **PerMgmtPack** and click **Save**.
- 9. Copy PerMgmtPack to the target CMS.
- 10. Log into the target CMS as administrator.
- 11. Select Start→Run.
- 12. Enter **Regedit** and click **OK.** The **Registry Editor** page appears.
- 13. Expand and select HKEY_LOCAL_MACHINE\SOFTWARE\HP\Proliant Essentials\Licensing\.
- 14. Open Import Registry file from registry menu.
- 15. Enter a path to the file ProEssen that is copied from the source CMS, and click **Open**. A message appears indicating that the registry file has been imported successfully.
- 16. Expand and select HKEY_LOCAL_MACHINE\SOFTWARE\HP\Performance Management Pack\.
- 17. Open Import Registry file from registry menu.
- 18. Enter a path to the file PerMgmtPack that is copied from the source CMS, and click **Open**. A message appears indicating that the registry file has been imported successfully.

Changing the IP address of a system running HP SIM and the Vulnerability and Patch Management Pack (VPM)

Changing the IP address of a system running HP SIM and VPM on the same system

To change the IP address of a system running HP SIM and VPM on the same system:

1. Update the system IP address. For example, change the IP address from 192.168.100.100 to 192.168.200.200.

Be sure that the server name *VPMSERVER* is resolved to the new IP address. For example, 192.168.200.200. To verify, run the following command:

```
ping VPMSERVER
```

The new IP address, (for example, 192.168.200.200) should appear as result of the ping command. If the new IP address does not appear, double-check network configurations.

Be sure that the Proxy Server configured for VPM is still reachable from the new IP address. To verify, run the following command after the IP address is changed:

```
ping PROXYSERVER
```

- 2. Go to the directory where VPM is installed. The default installation directory is C:\Program Files\HP\VPM. Make a backup copy of the files statcredentials.xml and simcredentials.xml. For example, statcredentials-backup.xml Edit statcredentials.xml and simcredentials.xml and change the IP address located at the definition <server ip> to the new IP address.
- 3. In the same directory, edit the file events.xml and change the IP address located at the definition <sysNimbusName>.
- 4. Copy the updated statcredentials.xml and simcredentials.xml to the STATConfigurations directory under the HP SIM directory tree. The default is C:\Program Files\HP\Systems Insight
 Manager\hpwebadmin\webapps\ROOT\mxportal\home\VPM\config.
- 5. Reboot the system.

Changing the IP address of systems running HP SIM and VPM on different systems

To change the IP address of systems running HP SIM and VPM on different systems:

Note: When VPM and HP SIM are installed different systems, the files must be modified on both systems.

You must update the IP addresses for both systems. On the VPM system, be sure that the server name **VPMSERVER** is resolved to the new IP address. To verify, run the command:

```
ping VPMSERVER
```

The new IP address should appear as result of the ping command. If the new IP address does not appear, double-check network configurations.

On the VPM server, be sure that the proxy server configured for VPM is still reachable from the new IP address. To verify, run the ping PROXYSERVER after the IP address is changed:

- 1. On the VPM server, go to the directory where VPM is installed. The default directory is C:\Program Files\HP\VPM. Make a backup copy of the files statcredentials.xml and simcredentials.xml. For example, statcredentials-backup.xml and simcredentials-backup.xml. Edit the file statcredentials.xml, and locate the definition <server.ip>. Change the IP address to the new VPM server IP address. Edit the file simcredentials.xml and locate the definition <server_ip>. Change the IP address to the new HP SIM server IP address.
- 2. On the VPM server, in the same directory, edit the file events.xml and change the IP address located at the definition <sysNimbusName>.
- 3. On the HP SIM server, go to the STATCOnfigurations directory under the HP SIM directory tree. The default is C:\Program Files\HP\Systems Insight

 Manager\hpwebadmin\webapps\ROOT\mxportal\home \STATConfigurations.

 Make a backup copy of the statcredentials.xml and simcredentials.xml. For example, statcredentials-backup.xml and simcredentials-backup.xml. Edit the file statcredentials.xml, and locate the definition <server.ip>. Change the IP address to the new VPM server IP address. Edit the file simcredentials.xml and locate the definition <server_ip>. Change the IP address to the new HP SIM server IP address.
- 4. Reboot both systems.

Post database migration

SSH Configuration

To ensure that DTF tasks function correctly, reinitialize the SSH key exchange by executing **mxagentconfig** to each of the managed systems.

Host files and templates

Copy the host files and templates manually from the source CMS to the target CMS. The host files and templates are located in the same location for source and target systems:

```
<HP SIM Install Folder>\config\discovery\hosts
And
<HP SIM Install Folder>\config\discovery\templates
```

Note: The above files are available in a system only if templates and host files were created in HP SIM. If the host files or templates were never created on a CMS, the specified folders are not present.

WBEM Indication configuration

To ensure that WBEM events are received correctly, reinitialize the WBEM subscription by executing **mxwbemsub** to each of the managed systems with WBEM providers installed. For example:

mxwbemsub -a -n <Managed systems with WBEM providers installed>

Configuration settings

Copy the globalsettings.props and nodesecurity.xml files from the source CMS and paste it under the corresponding folder on the target CMS. The globalsettings.props and nodesecurity.xml files are located under the same location for both source and target systems:

```
<HP SIM Install Folder>\config\
```

If required, go to <HP SIM Install Folder>\config\ from the target system. Open globalsettings.props file using Notepad. Update the CMS device key in globalsettings.props according to the device key value in the database.

Go to Control Panel > Administrative Tools -> Services and restart the HP SIM service.

WMI Mapper configuration

The target CMS will have the source CMS as the mapper proxy host. Change the WMI mapper proxy host with the target CMS.

- 1. Sign in to HP SIM on the target CMS system with administrative privileges.
- 2. Go to Options→Protocol Settings→WMI Mapper Proxy
- 3. Select the existing mapper proxy host and click **Delete**
- 4. Click **New** and type in the target CMS name or IP address and click **OK**
- 5. Run Identification task on managed systems with WBEM providers installed.

Migrating trusted system certificates from the source CMS to the target CMS

- 1. Sign in to HP SIM on the source CMS system with administrative privileges.
- 2. Select Options->Security->Certificates->Trusted Certificate.
- 3. Select a certificate and click **Export**.
- 4. Save the certificate locally.
- 5. Repeat steps 3 and 4 for all the certificates listed in **Trusted System Certificates** page.
- 6. Copy all the exported certificates to the target CMS system.
- 7. Sign in to HP SIM on the target CMS with administrative privileges.

- 8. Select Options→Security→Certificates→Trusted Certificate.
- 9. Click Import.
- 10. Click **Browse** and select a certificate.
- 11. Click **OK**.
- 12. Repeat steps 9 through 11 for all certificates, which are copied.
- 13. On the target CMS system, select **Start Menu→Settings→Control Panel→ Administrative Tools→Services.**
- 14. Restart the HP SIM service.

Steps to replicate certificates from the target CMS to trusted managed systems

- 1. Sign in to HP SIM on the source CMS with administrative privileges.
- 2. Select Configure→Replicate Agent Settings.
- 3. From **Select Target Systems** page, select all managed systems that already have the certificate from the source CMS configured.
- 4. Click Apply Selections and click Next.
- 5. Select the target CMS as source and click **Next**.
- 6. Select the source configuration settings as Trusted Certificate.
- Go to the HP System Management Homepage → HTTP
 Server → Settings → Trusted Certificate Properties → Trusted Certificate.
- 8. Click **Run Now**. The certificates are replicated on the managed systems.

Replicating the trusted certificates and trust mode from the source CMS to target CMS

- 1. Sign in to HP SIM on the source CMS system with administrative privileges.
- Select Configure→Replicate Agent Settings.
- 3. Select the target CMS as target from **Select Target Systems** page.
- 4. Click Apply Selections and click Next.
- 5. Select the source CMS as the source and click **Next**.
- 6. Select the source configuration settings as Trusted Certificate and Trust Mode.

- a. To select the source configuration settings as Trusted Certificate, go to HP
 System Management Homepage→HTTP Server→Settings→Trusted
 Certificate Properties→Trusted Certificate.
- b. To select the Trust Mode, go to HP System Management Homepage > HTTP Server -> Configuration Options Properties -> Trust Mode.

7. Click Run Now.

Migrating HP VMM/HP SMP with a local MSDE database to another HP VMM/HP SMP with remote MS SQL database

Note: This section refers to the HP Virtual Machine Management Pack 1.x or 2.0.x as HP VMM and HP Server Migration Pack 1.x or 2.0.x as HP SMP unless otherwise specified (for HP SIM 5.0 or 5.0.x).

Important: HP SMP 1.x/2.0.x can only be installed if HP VMM 1.x/2.0.x is installed because VMM versions 1.11, 2.0, 2.0.1, 2.0.2 are bundled with HP SIM 5.0.x versions.

Note: This section refers to HP Virtualization Management Software as VMM 2.x and SMP 2.x (for HP SIM 5.1), where x refers to 1 as VMM version 2.1 is bundled with HP SIM 5.1.

Important: VMM 2.x and SMP 2.x can be installed through single installer HP Virtualization management software.

Important: HP SIM must be migrated successfully for the migration of HP VMM and HP SMP to a new system to be successful.

To migrate HP VMM and HP SMP with local MSDE to a target HP VMM/HP SMP with remote MS SQL database:

1. Install HP SIM along with the HP VMM/HP SMP plug-ins on the target system where you want to migrate HP SIM along with HP VMM/HP SMP.

Important: The HP VMM installation detects the HP SIM database system and automatically creates a database on the same database system. Therefore, during the installation of HP SIM, be sure to point to the remote database system where SQL 2000 has been installed for migration.

- 2. After the installations are successful, go to **Control Panel→Administrative Tools→Services** and stop the following services:
 - HP System Insight Manager
 - HP Virtual Machine Management Service
 - HP Virtual Machine Management Web service

Note: If it is VMM 1.x, stop the HP Virtual Machine Management service and HP Virtual Machine Management Web service.

Note: If it is VMM 2.0 or VMM 2.x, stop the HP Virtual Machine Management service.

- 3. Go to the target database system where HP SIM and HP VMM database resides and login as administrator.
- 4. Select Start Menu→Programs→Microsoft SQL Server→Enterprise Manager.
- 5. Right-click on SQL Server Group and select New SQL Server Registration.
- 6. Click Next.
- Select the system running MSDE or manually enter the system name or IP address if it is not listed.
- 8. Click **Add** to add the system to **Added Servers** group.
- 9. Click Next.
- 10. Select the Windows authentication/SQL Server authentication.
- 11. Select the default **Group name** and click **Next**.
- 12. Click Finish.
- 13. Expand the **SQL Server Group**, select the local database, and then select **vmm_db_v X** (where **X** is the VMM version number of either 1 or 2).
- 14. Right-click the database **vmm db v X** and select **All Tasks**.
- 15. Select **Import Data**.
- 16. Click Next.
- 17. Select the system running MSDE as the source server and **vmm_db_v X** (where **X** is the VMM version number of either 1 or 2) database as the source database from the DTS Import/Export wizard. If the system is not listed, manually enter the system name or IP address.
- 18. Select the required authentication. Select **Windows Authentication** or **SQL Server Authentication**.
- 19. Click Next.
- 20. Select **[local]** as the destination server and **vmm_db_v X** (where **X** is the VMM version number of either 1 or 2) database as the destination database.
- 21. Select the required authentication. Select **Windows Authentication** or **SQL Server Authentication**
- 22. Click Next.
- 23. Select Copy objects and data between SQL Server databases and click Next.
- 24. Select **Include extended properties** and click **Next**. Leave all other options as default.
- 25. Select the default options and click **Next**.

- 26. Click **Finish**. The import process starts.
- 27. A message appears: Successfully copied objects from Microsoft SQL Server to SQL Server. Click OK.
- 28. Access the system where HP SIM, HP VMM and HP SMP are newly installed and login as administrator.
- 29. Once the installations are successful, go to **Control Panel** → **Administrative Tools** → **Services** and start the following services:
 - HP System Insight Manager
 - HP Virtual Machine Management Service
 - HP Virtual Machine Management Web service

Note: If it is VMM 1.x, start the HP Virtual Machine Management service and HP Virtual Machine Management Web service.

Note: If it is VMM 2.0 or 2.x, start the HP Virtual Machine Management service.

Note: If the source CMS system, which is running MSDE, is also a Virtual Machine Host, you must discover that system on the target CMS, which is the migrated system with the remote database.

- 30. Sign in to HP SIM as an administrator and go to the **VM** column on the All Systems table view page.
- 31. From the HP SIM All Systems page, all the Virtual Machine Hosts appear that are licensed with a critical status. Restart the HP VMM Agent Service to reset the status back to normal.

Note: To migrate HP VMM/HP SMP with a local SQL Express 2005 database to another HP VMM/HP SMP with remote MS SQL 2005 database follow the same steps provided in Importing the SQL Server 2005 Express database from the source CMS to the target CMS section.

To restart the HP VMM Agent Service:

- a. Go to the Virtual Machine Host machine and login as administrator for Windows or root for ESX.
- b. For Windows Virtual Machine Host, go to **Control Panel Administrative Tools Services** and restart HP Virtual Machine Management Agent service.
- c. For ESX Virtual Machine Host, enter the following command:

/etc/init.d/Service hpvmmcntsvc restart

For more information

Refer to the following for more information regarding the topics referenced in this paper.

Microsoft® SQL Express 2005

http://www.microsoft.com/sql/editions/express/default.mspx

Microsoft SQL Server 2005

http://www.microsoft.com/sql/default.mspx

Microsoft SQL Server 2000 Enterprise Edition

System requirements

www.microsoft.com/sql/evaluation/sysreqs/2000/default.asp

White papers on SQL Server 2000

http://www.microsoft.com/resources/documentation/sql/2000/all/reskit/en-us/default.mspx

Renaming SQL Server

http://msdn.microsoft.com/library/default.asp?url=/library/en-us/instsql/in_afterinstall_5r8f.asp

HP SIM 5.2

Overview and features

http://h18013.www1.hp.com/products/servers/management/hpsim/index.html

HP SIM quick specs

http://h18013.www1.hp.com/products/servers/management/hpsim/quickspecs.html

Microsoft® Windows® Registry

The System Registry

http://msdn.microsoft.com/library/default.asp?url=/library/en-us/dninvbs/html/thesystemregistry.asp

© 2006-2008 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Java is a U.S. trademark of Sun Microsystems, Inc. Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation.